Purse from a Candy bag

- instructions -

Pick a bag and make sure it is clean

Cut the top and bottom off and cut the sides
so you.have a front and a back panel

Strengthen the panels with plastic sheets


Choose a zipper in the right length

Attach the zipper to the front panel
(the sled facing the panel)

Sew the zipper on
(you might have to open the zipper)

Fold the zipper up and sew the edge down

Attach the zipper to the back panel

Attach the front and back side together with the wrong side facing out.

Make sure the zipper is aligned.

Sew all the way to the top and do all the stiches twice.

Cut out the corners

Sew the corners down

Turn and start to use